

SmartShop 4 Auto Loader Owner's Manual



SKU/Model Number(s):

MCNC SS4 Auto load 4x8 FANUC

LAGUNA

Laguna Tools
744 Refuge Way, Suite 200
Grand Prairie, TX 75050
lagunatools.com

SmartShop 4 Auto Loader Owner's Manual

Scope of This Manual

This manual outlines the basic procedures for unpacking, installing, and operating the SmartShop 4 Auto Loader with pre-labeler

For detailed instructions and videos, please go to www.lagunatools.com. Refer to www.lagunatools.com for the latest manual revision.

Customer Service

For technical support, please contact Laguna Tools Customer Service by phone 1-800-332-4094 or email customer_service@lagunatools.com. Please note the machine type in the subject line.

In the space provided, record the serial number, model number, and install date of the machine.

Serial No.	
Model No.	
Install Date:	

Copyright © 2025

Laguna Tools, Inc.

ALL RIGHTS RESERVED

This document contains material protected under International and Federal Copyright Laws and Treaties.

Any unauthorized reprint or use of this material is prohibited. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system without express written permission from the author/publisher. LAGUNA® and the LAGUNA Logo® are the registered trademarks of Laguna Tools, Inc.

DISCLAIMER

Laguna Tools is not responsible for errors or omissions. Specifications subject to change. Machines may be shown with optional accessories.

Revision 02 V02 DRAFT (03/13/2025)

Table of Contents

1.0 General Information and Safety	7
1.1 Overview.....	7
1.2 Safety Signs and Call-Outs	7
1.3 Intended Use	8
1.4 Safety Warnings	8
1.5 Additional Safety Information	9
1.6 Proposition 65 Warning of Harmful Exposure	10
2.0 Receiving the Machine.....	11
3.0 Machine Placement.....	13
3.1 Placement.....	13
3.2 Dust Collection	13
3.3 Electrical	14
3.4 Lighting	14
4.0 Overview	15
4.1 Features	15
4.2 Components	15
4.3 Control Cabinet.....	16
4.4 Off Loader Table.....	17
4.5 Router Table.....	18
4.6 Scissor Lift Table	20
5.0 Specifications and Dimensions	22
5.1 Common Vacuum Layout.....	23
5.2 Control Cabinet Dimensions.....	24
5.3 Specification Table	25

SmartShop 4 Auto Loader Owner's Manual

6.0 Compressed Air Requirements	26
7.0 Electrical and Vacuum Pump Requirements	27
8.0 Unloading and Unpacking the Machine	28
9.0 Assembly & Setup	30
9.1 Leveling the Machine.....	31
9.2 Leveling the Conveyor Table.....	34
9.3 Leveling the Scissor Table	34
10.0 Electrical Connections	35
10.1 Power supply	35
11.0 Compressed Air Connection	37
11.1 Connecting Air to the Machine	37
12.0 Dust Collection	38
13.0 Pre-Labeler	40
13.1 Removing & Installing Labels	40
14.0 Fanuc Controls	49
14.1 Control & Status Screen	49
14.2 Job Manager Screen	51
14.3 Upper Keypad Layout.....	53
14.4 Lower Keypad Layout.....	55
15.0 Operation and Test Run	60
16.0 Changing the Router Bit and Collet	62
16.1 Removing a Collet	65
17.0 Spoil Boards	66
18.0 Selecting the Correct Router Bit	69
18.1 Straight Router Bit	69

SmartShop 4 Auto Loader Owner's Manual

18.2 Up Shear Router Bit	69
18.3 Ball Nose Router Bit	70
18.4 Down Shear Router Bit.....	70
18.5 Combination Router Bit	71
18.6 Compression Router Bit	71
18.7 Form Router Bit	72
19.0 Manual Pulse Generator Mode (MPG) Handwheel.....	73
20.0 Jog Mode	74
20.1 Labeler Side	74
20.2 Machine (Spindle) Side	75
21.0 Position Button.....	76
21.1 Actual Position Labeler Side	76
21.2 Actual Position Machine Side.....	77
22.0 System Button	78
22.1 Machine Side.....	78
22.2 Labeler Side	79
23.0 Drill Block Screen.....	80
23.1 Drill Block Main Screen	80
24.0 OFS/SET Screen	81
25.0 Safe to Cut Materials.....	82
26.0 Alarm Message Screen	83
27.0 Tool Screen.....	85
28.0 Automatic Tool Changer.....	86
28.1 Executing Tool Call Commands (Tool Changes)	86
29.0 Tool Touch Off (TTO)	90

SmartShop 4 Auto Loader Owner's Manual

30.0 Setting the Origin	94
30.1 Machine Path.....	94
31.0 Homing the Machine	96
31.1 X-Axis	96
31.2 Y-Axis	96
31.3 Z-Axis.....	96
32.0 Service Screens.....	97
32.1 Drill Block Service Screen	97
32.2 I/O Input Screen	98
32.3 I/O Output Screen.....	100
32.4 Loader Setup	102
32.5 Machine Setup.....	103
32.6 ATC Setup Screen.....	104
32.7 Debug Screen.....	105
33.0 Help Screens.....	106
33.1 Machine M-Codes	107
33.2 Loader M-Codes	108
34.0 Emergency Recovery	109
35.0 Maintenance.....	110
35.1 Cleaning the Helical Racks	112
35.2 Cleaning the Spindle Tray	112
36.0 Troubleshooting	113
37.0 Warranties	116

1.0 General Information and Safety

1.1 Overview

SAVE THIS MANUAL. Keep this manual for the safety warnings, precautions, assembly, operating, inspection, and maintenance procedures. Read this Owner's Manual in its entirety prior to assembly or operation.

Read and understand all warnings and operation instructions before using any tool or equipment. Always follow basic safety precautions to reduce the risk of personal injury. Improper operation, maintenance, or modification of tools or equipment could result in serious injury or property damage. Laguna Tools equipment is designed for specific and limited applications. This product should not be modified nor used for any application other than its intended use.

PERSONAL SAFETY IS THE RESPONSIBILITY OF THE OPERATOR

1.2 Safety Signs and Call-Outs

DANGER

An imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

A potentially hazardous situation which, if not avoided, may result in death or serious injury.

CAUTION

A potentially hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTE

A helpful tip from Laguna Tools staff.

1.3 Intended Use

The machine is designed to cut wood, acrylics, wood-fiber composites, certain plastics, and non-ferrous metals. Do not use this machine for anything other than its intended use.

1.4 Safety Warnings

1. Failure to comply with safety instructions may lead to personal injury and/or damage to the equipment. Do not operate the machine unless familiar with all safety instructions, warnings, and signs.
2. Do not operate the SmartShop Auto Loader with the electrical cabinet door open—High Voltage Supply Inside.
3. The machine must be properly electrically grounded. The power supply must be connected with a permanently fixed electrical wire.
4. Keep children and non-operators away from the machine.
5. Operators must be familiar with the installation, operation, and service of the machine. Only proper operation can ensure the safe and smooth running of the machine.

WARNING

Automated machinery involves moving parts which pose a potential hazard to personnel. Be aware of machine movement at all times.

WARNING

Only allow qualified service personnel to do electrical installation or repair work, and always disconnect power before accessing or exposing electrical equipment to reduce risks.

CAUTION

Machine bits are sharp and pose a cutting hazard. Do not handle without gloves or while the machine is in operation.

1.5 Additional Safety Information

1. All motion parameters have been set up by Laguna Tools. If any modifications are required, please have a professional operator perform the changes.
2. Safety Signs should be attached to places that are easy to spot.
3. Use the machine only in clean areas free from excessive moisture or flammable objects.
4. The machine must be level. Level the machine if the ground is uneven.
5. Keep the machine, electrical cabinet, and surrounding area clear of obstructions and free from excessive moisture.
6. Keep the machine, electrical cabinet, and cables away from excessive heat, flammable substances, and sharp objects.
7. Do not attempt to exceed the limits of the machine.
8. Disconnect power to all system components when not in use, when changing accessories, and before servicing. Remove the switch keys or lock-out the machine to prevent unauthorized use and child-proof the workshop.
9. Exercise care with machine controls and around keypad to avoid unintentional start-up.
10. Keep cutting tools clean and sharp.
11. Lubricate and change accessories when necessary.
12. Cables and cords should be inspected regularly.
13. Keep controls clean and dry.
14. Keep a copy of this manual for future reference.
15. Perform daily inspection of the machine for damaged, loose, or improperly adjusted parts or any condition that could affect safe operation. For your own safety, do not operate the machine with damaged parts.
16. Stay alert at all times while operating the machine.
17. Always wear safety glasses and hearing protection.
18. Know where the emergency stop switch is located.
19. Never operate machinery under the influence of drugs or alcohol, when tired, or when distracted.

SmartShop 4 Auto Loader Owner's Manual

20. Do not wear clothing, apparel, or jewelry that can become entangled in moving parts. Always tie back or cover long hair. Wear non-slip footwear to reduce the risk of slipping and losing control or accidentally contacting cutting tool or moving parts.
21. Never stand on the machine. Serious injury may occur if the machine is tipped or if the cutting tool is unintentionally contacted.
22. Consult the Owner's Manual or Laguna Tools for recommended accessories. Using improper accessories will increase the risk of serious injury or damage.

1.6 Proposition 65 Warning of Harmful Exposure

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paint.
- Crystalline silica from bricks, cement, and other masonry products.
- Arsenic and chromium from chemically treated lumber.

The risk of exposure varies depending on frequency of use. To reduce exposure to these chemicals, work in a well-ventilated area and work with approved safety equipment, such as face or dust masks that are specifically designed to filter out microscopic particle



Fire Warning

Use extreme caution when cutting flammable materials such as wood or acrylic. Keep the machine clean by following the supplied maintenance schedule and always have a fire extinguisher ready to extinguish a fire. Take extreme caution when cutting acrylic materials as they are more volatile than other materials.

Never leave the machine running unattended.

The tools sold by Laguna Tools are safe when used properly, as described by the American National Safety Institute, the UL Standards of safe tool use, and the IEC standards of safe tool use. Laguna Tools is in no way responsible for injury or death that occurs while using this product.

2.0 Receiving the Machine

Following delivery and before the driver and riggers have left, inspect the packing, invoice, and shipping documents. Next, ensure there is no visible damage to the packaging or the machine. All damage must be noted on the delivery documents and signed by the receiver and the delivery driver. Contact Laguna Tools Customer Service as soon as possible in case of damage. It is advisable to photograph and document any shipping damage. The original packaging is required to return damaged equipment to Laguna Tools.

NOTE

Sawdust may be found in the machine upon arrival. This is because the machine has been tested prior to shipment from the factory and/or Laguna Tools. Laguna Tools tests all machines prior to shipping, but some adjustments may have to be undertaken by the customer. These adjustments are covered in the various sections of this manual.

Most large machinery will be delivered on a tractor trailer 48 to 53 feet long. Please notify a Sales Representative with any Delivery Restrictions. The customer is required to have a forklift (6000 lbs. or larger is recommended) with 72-inch forks or fork extensions.

3.0 Machine Placement

When unpacking the SmartShop Auto Loader, separate all enclosed items from the packing materials and inspect each for damage. Save the packaging materials until all issues concerning missing or damaged items have been resolved.

3.1 Placement

Select the area where the SmartShop Auto Loader will be operated. The physical environment where the machine is located is important to safe assembly and operation. Before removing the machine from its packaging consider the weight load, electrical installation requirements, lighting, dust collection, and space allocation available for the machine and accompanying materials.

Guidelines for properly placing the machine follow:

1. There should be sufficient area around the machine to facilitate easy access to the workpiece, perform maintenance, and provide a safe exit path in the event of an emergency.
2. Select a solid level floor rated to hold the weight of the machine and workpieces under both static and dynamic loads. Laguna Tools recommends concrete flooring. Consult a licensed and experienced professional if in doubt.
3. Position the machine close to a power source and dust collection.
4. Allow an area for the storage of workpiece materials, finished products, and tools.
5. Leave ample space around the machine for the operator to handle both the equipment and the materials being cut.
6. Leave enough space around the machine to open or remove doors/covers as required by the maintenance described in the Owner's Manual.
7. **Do not** place or operate the machine in a highly magnetic area.

3.2 Dust Collection

Allow enough space for proper dust collection from the machine. For optimal operation, ensure that the machine is in a dry environment, free from excessive moisture, extreme weather conditions, hazardous chemicals, or airborne abrasives.

3.3 Electrical

The machine requires permanent, direct power installed by a qualified electrician familiar with industrial best practices. Ensure that all power cords are protected from traffic, moisture, chemicals, or other hazards. For safety, always have a qualified electrician assess grounding and any further electrical needs.

3.4 Lighting

Ensure that the lighting your machine is placed under is sufficient to safely perform regular operation and maintenance. Any glares, shadows, or strobe lighting which may distract or prevent the operator from safely operating the machinery should be removed from the working area.

4.0 Overview

Engineered to excel and built for speed. The SmartShop Auto Loader, complete with clean sweep technology, is a game-changer for the cabinet making industry and those shops looking to produce the maximum number of orders with quick and reliable delivery times.

Primarily designed for the panel processing sector with automatic part labeling, industry leading Fanuc controls & 1500-Watt Fanuc servo drives. This revolutionary workhorse provides the speed and accuracy to handle your most demanding production level applications. Labeling by itself.

4.1 Features

- 18HP HSD Spindle 5,000-24,000 RPM
- Multiple Table Sizes
- 5×5 HSD Boring Block
- Automatic Loading & Off-Loading Tables
- Automatic Labelling System (optional)
- FANUC® Oi-MF Control System
- 1,500W FANUC® Servo Drive Motors
- Up To 3,000 IPM Rapid Speed
- 12 Position Servo Rotary Auto-Tool Changing System
- 6 Zone Vacuum Table
- Helical Rack & Pinion X,Y Axis, Ball Screw Z Axis
- Heavy-Duty One-Piece All-Steel Frame

4.2 Components

- One (1) SmartShop 4 Auto Loader Router Table
- One (1) Off Loader Conveyor Table
- One (1) Infeed Scissor Lift Table
- One (1) Control Cabinet with Fanuc controls
- Vacuum Pump(s)

4.3 Control Cabinet



①

Process Light: Illuminates different colors depending on the process that is underway.

Red Light -Alarm indication.

Yellow Light -Machine is in the manufacturing process.

Green Light -Machine is ready to perform the next process.

②

Fanuc Control Screen & Buttons: Used for displaying and inputting functions for the machine.

③

Manual Pulse Generator (MPG): Allows the operator to manually control the machine position in pulsating movements.


④

Main Disconnect: This switch turns all components ON/OFF.

4.4 Off Loader Table





- ① **Conveyor Table:** Area where the cut material is placed to be off loaded . There is a stop sensor on the end to prevent the material from falling off the table.
- ② **Dust Brusher:** A brush that removes any dust or debris from the cut material.
- ③ **Controller Box:** A box that houses the controls for the conveyor table.



- ④ **Dust Collection Port:** Catches and collects the dust runoff.
- ⑤ **Conveyor Table Motor:** This motor powers the conveyor table.


4.5 Router Table



SmartShop 4 Auto Loader Owner's Manual

- ① **Gantry:** The gantry straddles the bed and carries the Electro-Spindle and the X, Y and Z axes motion components. It is moved along the length of the bed by precision Helical Rack-and-Pinions with drive motors on each end of the gantry.
- ② **Dust Hood:** The dust shroud connects the dust collection vent to the spindle to create a controlled path for the dust to travel.
- ③ **4-Zone Vacuum Table:** The bed of the machine consists of a heavy steel all-welded frame with a composite worktable that is machined for use with a vacuum pump. The 4-zone vacuum table provides suction in four different zones that the operator can adjust.
- ④ **Air Control Valves:** Turns the table vacuum suction on/off.
- ⑤ **Dust Collection Hose:** Pathway for the dust to travel.
- ⑥ **16 Position Automatic Tool Changer (ATC):** Houses the tool cones in place and rotates to the called tool when commanded.
- ⑦ **Suction Cups for Product Transfer:** The suction cups lift the material up and hold it to transfer to the router table.
- ⑧ **Roller Table:** Uses roller wheels to help smoothly transfer material to the router table.

4.6 Scissor Lift Table




*Shown with pre-labeler (optional)

- ① **Contilever Gantry:** This gantry houses the printer and printer motor. This gantry helps label and align the workpiece.
- ② **Label Printer:** Prints and applies labels to material to be cut.
- ③ **Material Height Sensor:** This sensor automatically stops the lift when the loaded material is aligned with the roller table for unrestricted movement.
- ④ **Scissor Lift Table:** This table houses the loaded material that is to be cut.

SmartShop 4 Auto Loader Owner's Manual

5


Control Box: A box that houses the controls for the scissor lift table.




6

UP/DOWN Control Pedals: Raises/lowers the scissor lift when pedals are pressed.


5.0 Specifications and Dimensions



5.1 Common Vacuum Layout



5.2 Control Cabinet Dimensions



SmartShop 4 Auto Loader Owner's Manual

5.3 Specification Table

Specifications	
4x8 Model	
POWER REQUIREMENTS	220-240V , 45 amp (Vacuum Choice affects amps)
FOOTPRINT	104" x 421"
WORKING AREA (<i>RECOMMENDED</i>)	152" x 520"
GANTRY CLEARANCE	7"
SPINDLE	18HP, liquid cooled
SPINDLE RPM	5,000-24,000
RAPID TRAVEL	3,000 IPM (inches per minute)
MAMIMUM CUTTING SPEED	1,000
COMPRESSED AIR REQUIREMENTS (<i>FOR AUTOMATIC TOOL CHANGER</i>)	7-12 CFM (cubic feet per minute) @ 100 PSI (pounds per square inch) of clean dry air.
DUST PORT DIAMETER	8" (inches)
PRECISION HELICAL RACK AND PINION DRIVE SYSTEM FOR X AND Y AXES	25mm Heavy Duty Linear Bearing All Axes
CONTROLLER	Fanuc
TABLE TOP	Phenolic grid w/tee slots
SOLID STATE HOME SWITCHES	YES
HEAVY DUTY WELDMENT TUBULAR STEEL FRAME	3100 lbs (pounds) or 1406 kg (kilograms)
CENTRALIZED LUBRICATION SYSTEM FOR ALL AXES	YES
VACUUM TABLE ZONES	4 Zones w/ Valves

6.0 Compressed Air Requirements

This machine requires compressed air for the ATC (automatic tool changer). 7-12 CFM (cubic feet per minute) @ 100 PSI of clean dry air is required.

NOTE

It is recommended to attach an air dryer to the compressed air system to help reduce moisture in the lines.

Moisture in the lines can cause damage to the machine and reduce the supplied air quality.

7.0 Electrical and Vacuum Pump Requirements

The SmartShop Auto Loader requires permanent, direct power installed by a qualified electrician familiar with industrial best practices. Ensure that all power cords are protected from traffic, moisture, chemicals, or other hazards. For safety, always have a qualified electrician assess grounding and any further electrical needs.

The SmartShop Auto Loader machine requires a 220-240V power source (vacuum choice affects Amps)

The vacuum pump(s) power requirements depend on the model and quantity that is chosen.

VACUUM PUMP REQUIREMENTS				
	BECKER 8.6 HP	BECKER 12.1 HP (SK)	BECKER 17 HP	BECKER 24 HP
1 Pump (3 phase, 208V)	29A , 168CFM	35.4A, 174CFM	61.3A, 270CFM	72A, 335CFM
2 Pumps (3 phase, 208V)	58A, 336CFM	70.8A,348CFM	122.6A, 540CFM	144A, 670CFM
1 Pump (3 phase, 480V)	13A, 168CFM	16.7A, 174CFM	29.5A, 270CFM	34A, 335CFM
2 Pumps (3 phase, 480V)	26A, 336CFM	33.4A,348CFM	59A, 540CFM	68A, 670CFM

8.0 Unloading and Unpacking the Machine

NOTE

All shipping related claims for loss or damaged goods must be made to Laguna Tools within 24 hours of delivery.

Contact Laguna Tools customer service department to make claims for any damaged items/parts.

The original packaging is required to return damaged goods within the warranty period.

The machine should be delivered on a trailer by one or a combination of these methods:

1. In a crate
2. In a box
3. Heat shrunk in plastic
4. Sitting on a pallet

BEFORE unpacking your new machine, inspect the packaging, invoice, and the shipping documents supplied by the driver. When unpacking the machine, verify there are no signs of damage to the parts or machine you have received.

See the components section to cross reference the parts you should receive.

WARNING

The customer is required to have a forklift (6000 lbs. or larger is recommended) with 72-inch forks or fork extensions.

WARNING

Unload the machine with care. DO NOT pinch, crush, or damage any components that are on/around the machine.

SmartShop 4 Auto Loader Owner's Manual

WARNING

This machine is heavy. Seek assistance from an experienced professional if you have any doubt about the following unboxing or set up procedures.

DO NOT attempt any procedure that you feel is unsafe or you believe you do not have the physical capability of achieving.

CAUTION

When determining location, verify there is sufficient room around the machine. If you cannot fully open all the doors around the machine, it cannot be installed or serviced in the future if necessary.

Tools needed:

- Crowbar or prybar
- Forklift or pallet jack
- Drill with Phillips head bit
- Tin snips

BEFORE moving the machine to the desired location, verify that there is sufficient room around the dust collector to facilitate easy access to the workpiece, perform maintenance, and provide a safe exit in the event of an emergency.

1. Use a forklift (6000 lbs. or larger is recommended) with 72-inch forks or fork extensions to unload the machine from the trailer.
2. Move the machine to a desired location.
3. Use tin snips to cut and remove any straps.
4. Use a drill with Phillips head bit to remove any screws that are securing the machine to the pallet/crate.
5. If necessary, use the prybar to remove any surrounding wood.
6. Use the forklift to lift the machine and remove the pallet/crate.
7. Lower the machine gently to the floor.
8. Ensure that all parts/components are present and in good condition.

9.0 Assembly & Setup

WARNING

Do not connect to a power supply until set-up is complete. Do not perform any of the following steps, installations, or adjustments with the machine connected to a power source unless directed to do so.

Tools & items needed:

- Knife or cutting tool
 - Tin snips
 - Forklift (6000 lbs. or larger is recommended)
1. After unloading the machine, make sure that all straps, plastic wrap, and surrounding wood are removed.
 2. Use a forklift to remove the control cabinet from the machine.

CAUTION

Be cautious of the cords running from the electrical cabinet to the machine.

DO NOT rip or fray them when removing the electrical cabinet.

CAUTION

The vacuum pump is heavy and requires a forklift to move.

3. Use the forklift to remove the vacuum pump(s) from the table.
4. Remove any other components from the machine and set them to the side.

NOTE

All shipping related claims for loss or damaged goods must be made to Laguna Tools within 24 hours of delivery.

Contact Laguna Tools customer service department to make claims for any damaged items/parts.

The original packaging is required to return damaged goods within the warranty period.

9.1 Leveling the Machine

Before positioning the conveyor table and scissor lift table, the router table will need to be leveled first.

Tools & items needed:

- *Crescent wrench*
 - *Level*
 - *Forklift, pallet jack, or 2-ton floor jack*
 - *Six (6) leveling feet*
 - *Six (6) bolt/nut combos*
1. Place a level on the machine to see if it is level.
 - a. If the machine is level, installing the leveling feet is optional.
 - b. If the machine is not level, the leveling feet will need to be installed.

9.1.1 Installing the leveling feet on the Router Table

The machine comes with six leveling feet.

1. Use a forklift, pallet jack, or 2-ton floor jack to slightly lift the machine off the ground.



Figure 9–1: Pallet Jack Lifting the Machine

2. Align the metal feet to the feet hole(s)



Figure 9–2: Aligning the Metal Feet

3. Place the bolt/nut combo into the hole(s).
4. Turn the nut clockwise until it is snug against the metal.



Figure 9–3: Inserting and Turning Bolt Against the Metal Foot

5. Slowly lower the forklift or jack and move it away from the machine.
6. Place a level on top of the table to check for levelness.
7. Use the crescent wrench to turn the nut clockwise/counterclockwise to make any leveling adjustments.



Figure 9–4: Using a Crescent Wrench to Adjust and Tighten the Bolt/Nut Combo

8. Recheck for levelness and adjust as needed.




Figure 9–5: Checking for Levelness

9. Apply steps 1-8 to all six feet.

9.2 Leveling the Conveyor Table

The conveyor table is pre-installed with leveling feet.

1. Use the crescent wrench to turn the nut on the leveling feet clockwise/counterclockwise to make any leveling adjustments.

NOTE

We highly recommend aligning the conveyor belt with the dust collection port for seamless material transfer.

9.3 Leveling the Scissor Table

After all electrical and compressed air connection are made, the scissor table can be aligned with the rear of the router table and leveled by using the foot pedals.

10.0 Electrical Connections

Tools & Items Needed

- 10mm socket or wrench
- 7mm deep socket or wrench
- Phillips screwdriver



CAUTION

A qualified professional is required to perform the electrical installation.

The onsite technician will assist in the electrical installation process.

10.1 Power supply



WARNING

Do not connect to a power supply until the set-up is complete. Do not perform any of the following steps, installations, or adjustments with the machine connected to a power source unless directed to do so.

1. Use the included key to unlock the fasteners and open the side panel of the control cabinet.
Notice the ports on the outside bottom rear of the control cabinet.




Figure 10–1: Ports on the rear of Control Cabinet


SmartShop 4 Auto Loader Owner's Manual

2. There should be a power supply cord with a red, black, and brown wire inside. Run this power supply cord through one of the ports.
 - a. Push them through into the control cabinet.

3. Connect the ground wire (green) to the contacts shown in the figure to the right.
 - a. Use a Phillips screwdriver to tighten it.



4. Connect the red, black, and tan wires to the contactors.
 - a. Use a Phillips screwdriver to tighten them.



The technician on site will set up all other electrical connections.

11.0 Compressed Air Connection

This machine requires compressed air for the ATC (automatic tool changer). 7-12 CFM (cubic feet per minute) @ 100 PSI of clean dry air is required.

NOTE

It is recommended to attach an air dryer to the compressed air system to help reduce moisture in the lines.

Moisture in the lines can cause damage to the machine and reduce the air quality supplied to the machine.

Tools & Items Needed:

- *Air compressor with air hose (not supplied)*

11.1 Connecting Air to the Machine

1. Insert the air hose into the connector.




Figure 11-1: Air Hose and Connector

12.0 Dust Collection

Dust collection is required for this machine. This ensures that the machine can optimally perform.

A dust collection will come with these component(s):

- One dust collection machine

These other components the operator will need to purchase:

- Dust collector hose
- Dust shroud

NOTE

We recommend purchasing a dust collector that is capable of 3000-5000 CFM (cubic feet per minute) of suction power.

Dust collection can increase the air quality and cleanup of the workspace.

1. Fit the dust shroud (not supplied) to the two air cylinder rods and clamp in position with the clamping nuts.
2. Fit a dust collector hose (not supplied) to the dust shroud and secure with the clamp. Ensure it is tight.
 - a. If the clamp is loose, the hose and shroud can fall off.




Figure 12-1: Dust Collector & Shroud

NOTE

To avoid a trip hazard, we recommend suspending the dust collector hose from the ceiling.

Confirm there is sufficient slack when suspending it so that there is no restriction in movement.

Insufficient slack may break or damage the dust shroud and hose.

13.0 Pre-Labeler


The Pre-Labeler is a component that prints and applies labels to material to be cut,

13.1 Removing & Installing Labels


 **WARNING**

*The printhead may be hot and could cause severe burns.
Allow the printhead to cooldown.*


1. Raise the printer door.




2. Slide the media supply guide out and remove the empty roll.




4. Rotate the open lever upward.




5. Push down the peel assembly release lever.




6. Loosen the thumbscrew on the rewind spindle.



7. Slide the rewind flap out and fold it down.




8. Remove the roll from the rewind spindle.




9. Remove any labels that are dirty or damaged and properly discard them.

SmartShop 4 Auto Loader Owner's Manual

10. Insert a new roll onto the media hanger and push in the media supply guide all the way back.




11. From the media hanger, feed the label under the dancer assembly, through the media sensor, and under the printhead assembly.




SmartShop 4 Auto Loader Owner's Manual

12. Extend approximately 18 in. (500 mm) of media out of the printer. Remove the labels from this exposed media, leaving just the liner; keep one label for later use but discard the rest.




13. Feed the liner between the rubber roller and metal plate, pulling it through the big gap that's directly below the metal plate. The liner should sit between the two metal plates.




SmartShop 4 Auto Loader Owner's Manual

14. Place the liner against the back plate and slightly wrap it around the rewind spindle.
Choose a flat spot on the rewind spindle and stick the saved label on top of liner, sticking it to the spindle.
15. Hand-turn the spindle counterclockwise two rotations to help secure the media.




16. Slide the rewind flap in and fold it up.
17. Tighten the thumbscrew on the flap.




SmartShop 4 Auto Loader Owner's Manual


4. Rotate the printhead open lever downward to lock the printhead in place.



5. Push the peel-off release lever up to close the assembly.




6. Close the printer door.



14.0 Fanuc Controls

14.1 Control & Status Screen



- ① **Labeler Display Window-** Displays the X and Y coordinates on the labeler path.
- ② **Machine Display Window-** Displays the absolute coordinates on the machining path.
- ③ **Program Window(s)-** Displays the main program contents on each path
- ④ **Clear Table Button-** Only works when “M” (Machine path) is selected. Clears router table without loading the next sheet of material.

SmartShop 4 Auto Loader Owner's Manual

- ⑤ **Stage Panel**- Only works when "L" (Labeler) path is selected. Prepares the next piece of material on labeler for transfer.
- ⑥ **Load Panel**- Only works when "M" (Machine) path is selected. Transfers and aligns material
- ⑦ **Reset Labeler/Machine**- When "L" (Labeler) path is selected, the labeler resets all pistons and moves to the default position. When "M" (Machine) path is selected, all the rails and pushers do not move the machine.
- ⑧ **Feed 100 %** - Increases the feed rate of the selected path by 100% speed capacity.
- ⑨ **Feed Inc %** - Increases the feed rate of the selected path.
- ⑩ **Feed Dec %**- . Decreases the feed rate of the selected path
- ⑪ **Feed 10 %**- Increases the feed rate of the selected path by 10% speed capacity
- ⑫ **Help**- Opens the help screen.
- ⑬ **Warm Spindle**- Allows the spindle to reach a stable operating temperature before machining.
- ⑭ **Skip Load**- Skips the loading process and only executes machining G-code. Skip load is cleared on reset and rewind
- ⑮ **Load Queue**- Loads queue that is on file.
- ⑯ **Auto Queue**- Automatically starts next job file when activated. Hold 3 secs to activate. press feed hold to deactivate. Auto queue also deactivates when an alarm is present.
- ⑰ **Drill Block**- Opens the drill block screen.
- ⑱ **Tools**- Opens the tool screen.
- ⑲ **Job Manager**- Opens to the job manager page.
- ⑳ **Control Status**- Opens to the control status screen.
- ㉑ **Service**- Opens the service screen. Only available when PWE=1

14.2 Job Manager Screen

The job manager screen is a screen that shows the job(s), file(s), and material(s) that are uploaded to the controller.


The maximum number of files that can be in each list is as follows:

Job List: Up to 50

File List: Up to 100

Material List: Up to 10

Queue: Up to 100



① **Job List Window**-Lists the current job file(s) that are loaded into the controller.

SmartShop 4 Auto Loader Owner's Manual

- ② **Material List Window**-Displays the material(s) that are loaded into the job list.
- ③ **File List Window**- Displays the files in the selected materials folder.
- ④ **Job Queue Window**-Displays the job files in queue that are to be cut.
- ⑤ **Reload**-Updates the job list window if any new job file(s) were uploaded.
- ⑥ **Clear Done**-Moves finished job files from the Jobs List to the to the Done List
- ⑦ **Queue All / Clear Queue**- When "Queue All" is displayed, this button loads all files that are in the "File List Window" into the "Queue Window". When "Clear Queue" is displayed, this button moves all files in the "Queue Window" into the "File list Window".
- ⑧ **Load Queue**- Loads the start queue file. Holding the "M" or "L" button just loads the selected the path.
- ⑨ **Auto Queue**- Hold 3 secs to enable. Automatically starts the next job file in the queue.
- ⑩ **Job Manage**- Displays the job manager page.
- ⑪ **Loader Control**- Displays the Control and Status page.

14.3 Upper Keypad Layout



Reset: Resets the selected path to its default state. When in "Edit Mode", this rewinds the path.



Keypad-Can input letters, numbers, symbols, and other characters.



Alter: Use to overwrite selected data.



Insert: Inserts the selection.



Cancel: Deletes the last character or symbol that was inputted.



Delete: Deletes the selection.


SmartShop 4 Auto Loader Owner's Manual



Shift: Some buttons have subscript characters on them. This button toggles to the subscript character.



CSTM/GR: Toggles through screens one at a time.




Input: Inputs the selection.



Help: Displays the help screen that shows the operation of an MDI key.



Pos: Displays the true position screen.



Arrows: Used for navigation.



System: Displays the system menu screen.



Page Up/ Page Down: Used for full page navigation.



Prog: Displays the program menu screen.



Message: Displays the message & alarm screen



Offset Setting: Press to store work offsets and too length offsets.

14.4 Lower Keypad Layout



Auto: Starts the program automatically. This button will only function when “M” or “L” is selected.



Edit: Displays the edit screen. Edits the G Code. This button will only function when “M” or “L” is selected.



MDI: Manual Data Input. Allows the operator to manually enter commands. This button will only function when “M” or “L” is selected.



Remote: Not used.



Single Block: Not used.



Block Skip: Not used.



OPT STOP: Not used.




Teach: When prompted, can set values.

SmartShop 4 Auto Loader Owner's Manual



Restart: Not used.



PRG Stop: Stops the program.



MC Lock: Not used.



Ref: Enables the machine to reference mode. This allows the operator to home the machine during the initial setup or anytime the motor is unplugged.



Dry Run: Not used.



LC Cycle Stop: Stops the cycle on the Loader Control path. Pressing this will disable the "Auto Queue"



Jog: Moves the spindle one increment of measure. This button will only function when "M" or "L" is selected.



LC Cycle Start: Starts the cycle on the loader control path. Must be used simultaneously with machine path "cycle start"



Inc: Not used.



Cycle Stop: Stops the cycle on the machine path. Pressing this will disable the "Auto Queue"



Handle: Enables the operator to use the Manual Pulse Generator (MPG) handwheel. This button will only function when "M" is selected.




Cycle Start: Starts cycle on the machine path.



X 1: Sets the step distance incremental mode to .0001 times the speed.

SmartShop 4 Auto Loader Owner's Manual



x10: Sets the step distance incremental mode .001 times the speed.




X100: Sets the step distance incremental mode to .01 times the speed.



x1000: Sets the step distance incremental mode to .1 times the speed.




-Tc: Rotates the tool changer counter-clockwise.




+Tc: Rotates the tool changer clockwise.



Oil: Oils the machine.



Pump 1: Turns on vacuum pump 1.




Pump 2: Turns on vacuum pump 2.



PuP: Not Used



ALL OFF: Turns off all vacuum pumps and disengages pop up pins.




L: Selects the Labeler path as the active path.




M: Selects the Machine path as the active path.




EZ+: Returns to the "control and status screen" (home screen).



+Z: Raises the spindle along the Z-axis.



-Z: Lowers the spindle along the Z-axis.



+Y: Moves the spindle up along the Y-axis when the "M" path is selected. Moves the labeler up along the Y-axis when the "L" path is selected.


SmartShop 4 Auto Loader Owner's Manual



-Y: Moves the spindle down along the Y-axis when the "M" path is selected. Moves the labeler down along the Y-axis when the "L" path is selected.




+X: Moves the spindle up along the X-axis when the "M" path is selected. Moves the labeler up along the X-axis when the "L" path is selected.



-X: Moves the spindle down along the X-axis when the "M" path is selected. Moves the labeler down along the X-axis when the "L" path is selected.



Rapid: Quickly moves different axes when pressed simultaneously with corresponding axis button(s).



OT-OR: Not Used



Spindle Clockwise: Rotates the spindle clockwise




Spindle Stop: Stops the spindle from rotates



Spindle Counter-Clockwise: Rotates the spindle counterclockwise.

14.4.1 Dial Control Layout



- ① **Emergency Stop**-Stops all function(s).
- ② **Feed Dial**- Controls the cut rapid/jog feed rate on the machine path.
- ③ **Spindle Speed Dial**- Controls the spindle rotation speed.
- ④ Not used.

- ⑤ Not used.
- ⑥ Not used.
- ⑦ Not used.

15.0 Operation and Test Run


1. Verify that all electrical connections are connected correctly.
2. Turn ON the main power switch.
 - a. Wait for the machine to boot up.
3. Verify all design parameters and upload the design file from Mozaik or other CAD software.
 - a. If using Ethernet, file share the files to the control cabinet.
 - b. If using a USB thumb drive, drag and drop the files into the USB thumb drive.
 - i. Unplug the thumb drive and plug it to the USB slot on the control cabinet.




- ii. Press **PROG** > **Folder** > **Operate** > **Device change** > **USB**
- iii. Highlight the desired folder > **select** > **copy** > **device change** > **DTSVR** > **job folder** > **input** > **operate** > **paste**



4. Once the files are uploaded, press **JOB MANAGE**.



5. Highlight the desired job in the **job list** area and press **INPUT**.



6. Highlight the desired file(s) in the **file list** area and press **INPUT** to transfer them to queue.



7. Press **LOAD QUEUE** to queue the file(s).



8. Press the **AUTO QUEUE** button for 3 seconds to turn on auto queue.



9. Press **LC CYCLE START**.



10. Press **CYCLE START** cycle start on the machine path
11. Confirm that all components are running correctly.
12. Confirm that the material was cut correctly.
13. If all components work and the material was cut correctly, any job file can now be completed.

16.0 Changing the Router Bit and Collet

Tools needed:

- *Collet*
- *Spindle nut*
- *Tool cone*
- *Bit*
- *Spanner wrench*



Assembled Tool Cone

1. Select the desired router bit and a collet of correct size.
2. Press fit the collet into the spindle nut until snaps in place. There should be a “snap” sound if done correctly.



Figure 16–1: Pressing Collet into Spindle Nut

SmartShop 4 Auto Loader Owner's Manual

3. Grab and turn the tool cone upside down and place it in the tool bracket as shown in Figure 16-2 below.




Figure 16-2: Tool Cone in the Tool Bracket

4. Place the spindle nut over the tool cone.



Figure 16-3: Spindle Nut on Cone

SmartShop 4 Auto Loader Owner's Manual

5. Place the desired bit into the nut.
 - a. There is a reference point on the bit. **DO NOT** go past this point. The flute (sharp slots) of the router bit should be a minimum of 1/16 inch outside the collet. The bit should not bottom out in the tool cone.



Figure 16–4: Placing Bit into the Collet

6. Hand-tighten the nut and then turn a spanner wrench clockwise to tighten it until snug. **DO NOT** overtighten it.




Figure 16–5: Tightening Spindle Nut with Spanner Wrench

7. Remove the assembled tool cone from the bracket and place it in the ATC (auto tool changer) rack.

NOTE

The router bit must not be fitted into the collet until the collet has been fitted into the spindle nut. With the router bit fitted in the collet, the collet cannot compress and snap into the spindle nut.

16.1 Removing a Collet

To remove the collet:

1. Remove the tool cone from the spindle and place it in the tool bracket.
2. Loosen the spindle nut using the spanner wrench.
3. Remove the router bit if there is one in the collet
 - a. Allow the bit to cool down if it's hot.
4. Remove the spindle nut from the tool cone.
5. Hold the spindle nut in place and squeeze the collet inward. (the collet will compress)
6. Pull the collet out of the spindle nut. (it might take a lot of force)
7. Select a new collet and press fit into the spindle nut until a "snap" sound is heard.

NOTE

Keep the collets clean and blow all dust out of the slots. Fine dust accumulates and will affect the clamping ability and cut quality.

17.0 Spoil Boards

Spoil boards (supplied) are boards that help protect the vacuum table from damage from machining.

A sheet of porous material (usually MDF [Medium-Density Fiberboard]) is bolted down on top of the vacuum table.



The panel material that is to be machined is placed on top of the spoil board, and the vacuum passes through the through it and holds the panel material down as it is machined.

The purpose is to limit vacuum infiltration through grooves in the spoil board. This also allows the processing of various nests without any setup time on the machine.

17.1.1 Functions of the Spoil Board

1. To protect the vacuum table from damage. The cutter extends only a few thousandths of an inch past the material thickness. Without the spoil board, the cutters could damage the surface of the vacuum table.
2. To transfer the vacuum suction from the table to the job. This means that the spoil board must be porous to allow air flow to the panel material. Low cost MDF (Medium-Density Fiberboard) has proven to be a very good material for this purpose.

17.1.2 Making the Spoil Board

Before making a new spoil board, ensure all plastic bolts are removed from the old spoil board.

The spoil board is made of 4' x 8' $\frac{3}{4}$ " MDF board that is bolted down to the machine using $\frac{1}{2}$ " plastic bolts.

NOTE

We highly recommend using a $\frac{3}{4}$ inch thick MDF spoil board to help prevent damage to the vacuum table.

MDF is a very porous material, which allows the vacuum table suction to flow through the board and hold the material in place.

NOTE

Never try to use a bowed (curved) MDF panel as a spoil board. The vacuum may not pull the board flat on the table.

1. Remove all bolts that hold down the spoil board and remove the old spoil board.
2. Make sure that the table is clean and free from sawdust and dirt.
3. Cut the spoil board to the size of the router table (4' x 8')
4. Place the spoil board on the vacuum table, being careful not to displace the vacuum gasketing.
5. Install and tighten the plastic bolts back into their respective ports.
6. Turn on the vacuum pump(s) and check for leaks.



Figure 17-1: $\frac{1}{2}$ inch Plastic Bolt for Spoil Board

NOTE

We recommend sealing the edges of the spoil board with hard candle wax or non-water based products. Sealing the edges will improve the holding ability.

17.1.3 Precautions Regarding Spoil Boards

The spoil board is porous and will absorb moisture. As moisture is absorbed, the dimensions of the board will change.

In general, this will not be a problem, as the changes from day to day are not that excessive and will typically be over the complete board.

There are, however, exceptions:

1. It is good practice to keep material on the top surface of the spoil board overnight to prevent warpage due to uneven moisture absorption by the material.
2. Once a spoil board has been used and has kerf cuts that resulted from machining parts, it is a good idea to replace, or fly cut the surface.
3. The spoil board must completely cover the table and must be properly bolted down. If the spoil board is not bolted down or does not cover all the vacuum slots, the vacuum suction may be lost or not exist. This will cause the panel material to not pull down onto the spoil board effectively.



WARNING

Do not touch the vacuum pump while operating. Surface temperature of blowers will be more than +140 Degree Fahrenheit/+60 Degree Celsius

18.0 Selecting the Correct Router Bit

18.1 Straight Router Bit

These are the standard router bits that are commonly used with handheld routers and are readily available at home centers. They will work but will generally not produce the edge finishes that are available with the spiral designed router bits.



Figure 18-1: Straight Router Bits

18.2 Up Shear Router Bit

These bits have flutes that are spiraled upward (a standard twist drill is an example of this type of bit). This bit design removes the chips from the kerf (slit made by cutting) but tends to chip the top surface, especially on veneers or melamine surfaces.




Figure 18-2: Up-shear Router Bits

18.3 Ball Nose Router Bit

Ball nose router bits are a variation of the up-shear bit design but have radiused on the ends. These bits are typically used for 3D surfacing applications.



Figure 18–3: Ball Nose Router Bit

18.4 Down Shear Router Bit

These bits are like the up shear, but with an opposite spiral that tends to pack the chips into the kerf. These bits prevent chipping the material surface, especially with veneers or melamine surfaces. They are an excellent choice for machining dadoes and other joinery that do not extend completely through the material.




Figure 18–4: Down Shear Router Bit

18.5 Combination Router Bit

These bits combine the advantages of both up shear and down shear designs. The top section of the tool is down shear to prevent chipping the top surface of the material, and the lower part of the bit is up shear to prevent chipping the bottom surface of the material.



Figure 18–5: Combination Router Bit

18.6 Compression Router Bit

Compression router bits are the preferred bit for machining veneered plywood as well as melamine-surfaced product. A variation of the bit is called the “Mortising Compression” router bit. With this bit, the up shear portion of the bit is less than $\frac{1}{4}$ " in length so that the bit can be used on $\frac{1}{4}$ " veneered plywood and for dados.




Figure 18–6: Compression Router Bit

18.7 Form Router Bit

Form router bits typically are available in standard profiles such as round over, ogee, cove, etc. Router bits that have a shape associated with them would be classified with this group.





Figure 18-7: Form Router Bits

19.0 Manual Pulse Generator Mode (MPG) Handwheel

The manual pulse generator mode allows the operator to manually to move the spindle axes by spinning the MPG Handwheel.









1. Press the  button to enable to MPG handwheel. (a light on the MPG will illuminate.)
2. Select the desired axis to move
 - a. *The 4 and 5 function are not used.*
3. Turn the handwheel in the clockwise (CW) direction to move the spindle in the positive direction .
4. Turn the handwheel in the counterclockwise (CCW) direction, the machine will move in the negative direction. The speed is determined by the selected speed value.









20.0 Jog Mode


Jog mode allows the operator to jog the spindle or labeler in small increments in different directions.













20.1 Labeler Side

1. Press the  button.
2. Press the  button.
3. Press the  or  buttons to move the labeler up/down along the x-axis.
4. Press the  or  buttons to move the labeler up/down along the y-axis.

20.2 Machine (Spindle) Side

1. Press the  button.
2. Press the  button.
3. Press the  or  buttons to move the spindle up/down along the X-axis.
4. Press the  or  buttons to move the spindle up/down along the Y-axis.
5. Press the  or  buttons to raise/lower the spindle along the Z-axis.


Press the  button simultaneously with the corresponding axis button(s) to quickly move the spindle.

	+		=	Quickly lowers the spindle height along the z-axis.		+		=	Quickly raises the spindle height along the z-axis.
	+		=	Quickly moves the spindle up, along the y-axis.		+		=	Quickly moves the spindle down, along the y-axis.
	+		=	Quickly moves the spindle to the left, along the x-axis.		+		=	Quickly moves the spindle to the right, along the x-axis.

21.0 Position Button

21.1 Actual Position Labeler Side



While the  path is selected, Press the  button to toggle to the actual position screen.

This screen displays the coordinates for the labeler.



21.2 Actual Position Machine Side



When the **M** path is selected, Press the **POS** button to toggle to the actual position screen.

This screen shows the coordinates of the spindle location.



ACTUAL POSITION		09000 N00000	
ABSOLUTE		F	0.00 INCH/M
X ₁	1.7708	PARTS COUNT	311
Y ₁	4.9917	RUN TIME	0H 0M55S
Z ₁	-1.0071	CYCLE TIME	0H 0M 0S
W ₁	38.740	GRAPHIC PARAMETER	
Y _S	4.9627	GRAPHIC COORDINATES	0
G00 G80 G15 F3.937007 M		(XY=0, YY=1, YY=2, XY=3, XYY=4, YXY=5)	
G17 G98 G40.1 H		SCALE	1.00
G90 G50 G25 D		GRAPHIC CENTER	X1 0.0000
G22 G67 G160 T		Y1 0.0000	
G94 G97 G13.1 S		YS 0.0000	
G20 G54 G50.1		RANGE<MAX.>	X1 0.0000
G40 G64 G54.2		Y1 0.0000	
G49 G69 G80.5		YS 0.0000	
TOLERANCE 0.0000		RANGE<MIN.>	X1 0.0000
		Y1 0.0000	
		YS 0.0000	
S 0	SOV 100	A>^	
		FINE	
		JOG **** * * * *	11:52:45 MACHINE
ABSOLUTE	RELATIVE	ALL	HANDLE
		PARAMETER	GRAPH
			(OPRT)

22.0 System Button

These screens below show the parameters for the selected paths.

22.1 Machine Side



When  is selected and the  button is pressed, the parameter screen below is shown.

PARAMETER 09000 N00000

00000	0	0	0	0	0	INI	ISO	TVC	00021	OUT CHANNEL/F. G.	0	
00001	0	0	0	0	0	1	0	0	00022	INP CHANNEL/B. G.	0	
00002	0	0	0	0	0	0	0	0	00023	OUT CHANNEL/B. G.	0	
00010	0	0	0	0	0	0	0	0	00024		0	
00012	0	0	0	0	0	0	0	0	00100	ENS IOP	0 0 0 0	
X1	0	0	0	0	0	0	0	0		NCR CRF CTU	0 0 0 0	
Y1	0	0	0	0	0	0	0	0	00101	NFD	1 0 0 0	
YS	0	0	0	0	0	0	0	0		ASI	0 0 0 1	
Z1	0	0	0	0	0	0	0	0	00102	IO SELECT CH0	0	
W1	0	0	0	0	0	0	0	0	00103	BAUDRATE CH0	10	
00020	I/O CHANNEL										00110	I04
	17										0	0 0 0 0



A>_

REF **** * * * * 11:40:17 MACHINE

PARAME TER DIAGNO SIS SERVO GUIDE SYSTEM (OPRT)

22.2 Labeler Side



When  is selected and the  button is pressed, the parameter screen below is shown.

PARAMETER 09000 N00000

00000	0	0	0	0	0	1	0	0	00023	OUT CHANNEL/B. G.	0
00001	0	0	0	0	0	0	0	0	00024		0
00002	0	0	0	0	0	0	0	0	00100	ENS IOP	0 0 0 0
00010	0	0	0	0	0	0	0	0	00101	NFD	0 0 0 0
00012	0	0	0	0	0	0	0	0	00102	IO SELECT CH0	0
XL	0	0	0	0	0	0	0	0	00103	BAUDRATE CH0	10
YL	0	0	0	0	0	0	0	0	00110		0 0 0 0
00020	0	0	0	0	0	0	0	0	00111	NFD	0 0 0 0
00021	0	0	0	0	0	0	0	0	00112	IO SELECT CH1	0
00022	0	0	0	0	0	0	0	0			

00020 I/O CHANNEL: 17

00021 OUT CHANNEL/F. G.: 0

00022 INP CHANNEL/B. G.: 0

A > ^

JOG **** * * * * 11:39:56 LABELER

PARAMETER DIAGNOSIS SERVO GUIDE SYSTEM (OPRT)

23.0 Drill Block Screen

23.1 Drill Block Main Screen

DRILL BLOCK INPUT VALUE:

SPNDL MODE
DRILL MODE
ALL UP
ALL DOWN
DRILL UP/DN
MEASURE DRILL
COPY TO ALL

DRILL	LENGTH
T21	-5.8810
T22	-5.8810
T23	-5.8810
T24	-5.8810
T25	-5.8810
T26	-5.8810
T27	-5.8810
T28	-5.8810
T29	-5.8810

MACHINE

X	24.0000	INCH
Y	90.0000	INCH
Z	0.0000	INCH

* MACHINE LABELER

MEM EDIT *** ***** **

S CTRL STATUS JOB MANAGE TOOLS DRILL BLOCK T21 T22 T23 T24 T25 >

24.0 OFS/SET Screen



When **M** is selected and the **OFS/SET** button is pressed, this will be the screen displayed.

This screen shows a more in depth look at the spindle coordinates and measurements.

This screen shows the tool lengths, drill lengths, and work offsets & drill offsets

OFFSET
09000 N00000

NO.	(LENGTH)		(RADIUS)		RELATIVE	
	GEOM	WEAR	GEOM	WEAR		
001	-8.7008	0.0000	0.0000	0.0000	X1 0.0000	
002	-8.3789	0.0000	0.0000	0.0000	Y1 0.0000	
003	-8.6800	0.0000	0.0000	0.0000	Z1 0.0000	
004	-8.8663	0.0000	0.0000	0.0000	W1 0.000	
005	0.0000	0.0000	0.0000	0.0000	YS 0.0000	
006	0.0000	0.0000	0.0000	0.0000	ABSOLUTE	
007	0.0000	0.0000	0.0000	0.0000	X1 1.7708	
008	0.0000	0.0000	0.0000	0.0000	Y1 4.9917	
009	0.0000	0.0000	0.0000	0.0000	Z1 -1.0071	
010	0.0000	0.0000	0.0000	0.0000	W1 38.740	
011	0.0000	0.0000	0.0000	0.0000	YS 4.9627	
012	0.0000	0.0000	0.0000	0.0000	MACHINE	
013	0.0000	0.0000	0.0000	0.0000	X1 5.7953	
014	0.0000	0.0000	0.0000	0.0000	Y1 27.4153	
015	0.0000	0.0000	0.0000	0.0000	Z1 -0.4344	
016	0.0000	0.0000	0.0000	0.0000	W1 38.740	
016	0.0000	0.0000	0.0000	0.0000	YS 27.3863	

A>^
FINE

JOG **** ** *
11:50:08
MACHINE

←
OFFSET
SETTIN
WORK
(OPRT)
→

25.0 Safe to Cut Materials

This machine can cut multiple materials including:

- Any type of wood
- Wood-fiber composites
- High Density foam
- Plastics
- Non-ferrous metals (*not iron based*)



Any Type Of Wood



High-Density Foam



Plastics




Non-Ferrous Metals

26.0 Alarm Message Screen

The alarm message screen displays any alarm or error message that is present.

To access the alarm message screen:



1. Press  to view any alarm messages.




SmartShop 4 Auto Loader Owner's Manual

If an alarm is present, a screen with an alarm message will be shown. The figure below is an example of an alarm message.



26.1.1 Clearing Alarms

1. After the issue has been resolved, press  while on the alarm message screen to clear any alarms.

27.0 Tool Screen

This screen shows the tools that are inputted into the machine.

It also shows the tool number that is currently active.



- Performs a tool touch off on the selected tool.



-Loads the selected tool into the spindle.



- Parks the active tool that is in the spindle.

Tools

INPUT VALUE:

TOOL	LENGTH	RADIUS	TOOL	LENGTH	RADIUS
1	-8.6691	0.0000	9	0.0000	0.0000
2	-8.2184	0.0000	10	-8.1765	0.0000
3	-8.6659	0.0000	11	-8.2941	0.0000
4	-8.6683	0.0000	12	0.0000	0.0000
5	-8.2400	0.0000	13	0.0000	0.0000
6	-9.0376	0.0000	14	0.0000	0.0000
7	-8.3717	0.0000	15	0.0000	0.0000
8	0.0000	0.0000	16	-8.3872	0.0000

	ABSOLUTE	MACHINE	
X	52.0138	56.0383	INCH
Y	23.0464	45.4700	INCH
Z	-1.4100	-0.7200	INCH

TOOL NUMBER: 0

SPINDLE SPEED: 0 RPM

ACTUAL FEEDRATE: 0.00 IPM

* MACHINE MEM *** **

LABELER MEM *** **

S

CTRL STATUS

JOB MANAGE

TOOLS

DRILL BLOCK

TOUCH OFF

LOAD TOOL

PARK TOOL

?

28.0 Automatic Tool Changer

The automatic tool changer (ATC) adds another layer of automation to the CNC machine. The advantages of an automatic tool changer are as follows:

- ATC increases the machine's productivity
- Helps to minimize total machining time
- Increases the flexibility of the CNC Machine
- Improves tool carrying capacity of the CNC Machine

28.1 Executing Tool Call Commands (Tool Changes)

The ATC supports 12 tools. Tool changes are made by executing tool call commands. A tool call command parks the current tool if one is loaded, and loads the desired tool. There are two options to execute a tool call command.

To execute a tool call command:

Option 1 (recommended)

Tools INPUT VALUE:

TOOL	LENGTH	RADIUS	TOOL	LENGTH	RADIUS
1	-8.6691	0.0000	9	0.0000	0.0000
2	-8.2184	0.0000	10	-8.1765	0.0000
3	-8.6659	0.0000	11	-8.2941	0.0000
4	-8.6683	0.0000	12	0.0000	0.0000
5	-8.2400	0.0000	13	0.0000	0.0000
6	-9.0376	0.0000	14	0.0000	0.0000
7	-8.3717	0.0000	15	0.0000	0.0000
8	0.0000	0.0000	16	-8.3872	0.0000

	ABSOLUTE	MACHINE	
X	52.0138	56.0383	INCH
Y	23.0464	45.4700	INCH
Z	-1.4100	-0.7200	INCH

TOOL NUMBER: 0
 SPINDLE SPEED: 0 RPM
 ACTUAL FEEDRATE: 0.00 IPM

* MACHINE MEM *** **** ** ***** **
 LABELER MEM *** **** ** ***** **

Buttons: CTRL STATUS, JOB MANAGE, TOOLS, DRILL BLOCK, TOUCH OFF, LOAD TOOL, PARK TOOL

1. Use the arrow keys to highlight the desired tool.



2. Press

⚠ WARNING




The machine will move! Keep all body parts away!


SmartShop 4 Auto Loader Owner's Manual

Option 2

Tool Commands	Description
T0	Parks Tool
T1-T12	Changes tool, activates last stored tool measure.

To execute a tool call command:


1. Press 
2. Press 
3. Press 
4. Type in **M06T#** (# represents any desired tool number 0-12)
 - a. For example, if tool number 12 was desired, **M06T12** would be typed in.
 - b. For example, if tool number 4 was desired, **M06T4** would be typed in.
 - c. Any tool that is in the spindle will be parked before a new tool is loaded.




SmartShop 4 Auto Loader Owner's Manual



5. Press (a semicolon will appear)



SmartShop 4 Auto Loader Owner's Manual



6. Press

- a. The command code will be displayed on the left side.



5. Press

- a. **WARNING! THE MACHINE WILL MOVE! KEEP ALL BODY PARTS AWAY!**

29.0 Tool Touch Off (TTO)

A Tool touch off (TTO) is used to measure different tool lengths. When a tool touch off is performed, the machine spindle moves to the TTO puck and touches it three times. There are two options to execute a tool touch off.

To execute a tool touch off:

Option 1 (Recommended)

Tools INPUT VALUE:

TOOL	LENGTH	RADIUS	TOOL	LENGTH	RADIUS
1	-8.6691	0.0000	9	0.0000	0.0000
2	-8.2184	0.0000	10	-8.1765	0.0000
3	-8.6659	0.0000	11	-8.2941	0.0000
4	-8.6683	0.0000	12	0.0000	0.0000
5	-8.2400	0.0000	13	0.0000	0.0000
6	-9.0376	0.0000	14	0.0000	0.0000
7	-8.3717	0.0000	15	0.0000	0.0000
8	0.0000	0.0000	16	-8.3872	0.0000

ABSOLUTE MACHINE
 X 52.0138 56.0383 INCH
 Y 23.0464 45.4700 INCH
 Z -1.4100 -0.7200 INCH

TOOL NUMBER: 0
 SPINDLE SPEED: 0 RPM
 ACTUAL FEEDRATE: 0.00 IPM

* MACHINE MEM *** *** *** *****
 LABELER MEM *** *** *** *****

S CTRL STATUS JOB MANAGE TOOLS DRILL BLOCK TOUCH OFF LOAD TOOL PARK TOOL ?

1. Use the arrow keys to highlight the desired tool.

2. Press .







WARNING

THE MACHINE WILL MOVE! KEEP ALL BODY PARTS AWAY!

Option 2


To execute a tool touch off:

1. Press 
2. Press 
3. Press 
4. Type **M401T#** (# represents any desired tool number 0-12)
 - a. For example, if tool number 12 was desired, **M401T12** would be typed in.
 - b. For example, if tool number 4 was desired, **M401T4** would be typed in.




SmartShop 4 Auto Loader Owner's Manual



5. Press  (a semicolon will appear)



SmartShop 4 Auto Loader Owner's Manual



6. Press

a. The command code will be displayed on the left side.




7. Press


a. **WARNING! THE MACHINE WILL MOVE! KEEP ALL BODY PARTS AWAY!**

30.0 Setting the Origin

30.1 Machine Path

1. Press 

2. Press  until the screen shown below is displayed.



The screenshot displays the machine's control interface with the following data:

ACTUAL POSITION				09000 N00000					
RELATIVE		ABSOLUTE		F		0.00 INCH/M			
X1	0.0000	X1	0.8377	PARTS COUNT		311			
Y1	0.0000	Y1	4.9918	RUN TIME		0H 0M55S			
Z1	0.0000	Z1	-0.9958	CYCLE TIME		0H 0M 0S			
W1	0.000	W1	38.740	WORK COORDINATES					
YS	0.0000	YS	4.9620	(G54)					
MACHINE		DISTANCE TO GO		NO.	DATA	NO.	DATA		
X1	4.8622			000	X1	4.0245	001	X1	0.0000
Y1	27.4154			EXT	Y1	22.4236	G54	Y1	0.0000
Z1	-0.4231				YS	22.4236		YS	0.0000
W1	38.740				Z1	0.5727		Z1	0.0000
YS	27.3856				W1	0.000		W1	0.000
G00 G80 G15 F3.937007 M									
G17 G98 G40.1 H									
G90 G50 G25 D									
G22 G67 G160 T									
G94 G97 G13.1 S									
G20 G54 G50.1									
G40 G64 G54.2									
G49 G69 G80.5 TOLERANCE 0.0000									
S 0 SOV 100				A>_					
				FINE					
				JOG **** * * * * 11:32:38 MACHINE					
ABSOLUTE	RELATIVE	ALL	HANDLE	OFFSET	SETTING	WORK	OPRT		

3. Jog the spindle to the lower left corner of the spoil board.

4. Press  on the screen.

SmartShop 4 Auto Loader Owner's Manual

ALL

5. Press

Coordinate Description	
X1	X axis coordinates
Y1	Y axis coordinates
YS	Y slave axis coordinates
Z1	Spoil board thickness
W1	Tool changer

6. Type the **machine** coordinates into the **work** coordinates.
 - a. For the **YS work coordinates**, enter 0
 - b. Do not type in any **W1 work coordinates**.

31.0 Homing the Machine

Homing the machine will ensure that the machine positioning is accurate and that accurate cuts can be made.

31.1 X-Axis

1. Press 

2. Press  and then press 

31.2 Y-Axis

1. Press 

2. Press  and then press 

31.3 Z-Axis

1. Press 

2. Press  and then press 

32.0 Service Screens



To access the service screen press .

The service screen(s) allows the operator to view internal codes that can be viewed for operating and troubleshooting concerns.

Parameter Write Enable (PWE) must equal 1 for the service screen to appear.

```
PARAMETER WRITE= 1 (0:DISABLE 1:ENABLE)
```

This is set by Laguna Tools and will not need to be accessed unless there are certain troubleshooting issues.

32.1 Drill Block Service Screen

DRILL BLOCK

INPUT VALUE:

↶ ↷ ↶ ↷ ↶

↶ ↷ ↶ ↷

DRILL	X	Y
P21	8.6932	5.8034
P22	8.6932	4.5435
P23	8.6932	3.2837
P24	8.6932	2.0238
P25	8.6932	0.7640
P26	9.9530	0.7640
P27	11.2129	0.7640
P28	12.4727	0.7640
P29	13.7326	0.7640

↶ ↷ ↶ ↷

↶ ↷ ↶ ↷

↶ ↷ ↶ ↷

	RELATIVE	MACHINE	
X	0.0000	49.3246	INCH
Y	-0.3733	125.0700	INCH MACHINE
Z	0.0000	-0.1275	INCH LABELER

EDIT

MDI

<

CONFIG

MANUAL CTRL

I/O IN

I/O OUT

DRILL BLOCK

LDR SETUP

MCN SETUP

ATC SETUP

FP DEBUG

?

SPNDL MODE

DRILL MODE

ALL UP

ALL DOWN

DRILL UP/DN

TEACH DRILL

COPY TO ALL

SET SPINDLE

32.2 I/O Input Screen



Use the buttons to toggle through the screens.

I/O – Input 1/3

X20.0 MPG – X1 Select	OFF	X20.1 MPG – X10 Select	OFF
X20.2 MPG – X100 Select	ON	X20.3 MPG – X-Axis Select	ON
X20.4 MPG – Y-Axis Select	OFF	X20.5 MPG – Z-Axis Select	OFF
X20.6 Spindle Stopped	ON	X20.7 TTO Switch	ON
X21.0 Tool Gripped	ON	X21.1 Tool Release	OFF
X21.2 Drill Block Down	OFF	X21.3 Drill Block Up	ON
X21.4 Unused	OFF	X21.5 Spindle @ RPM	OFF
X21.6 All Axis Overtravel	ON	X21.7 Tool Release Switch	OFF
X22.0 X-Axis Home Switch	ON	X22.1 Y-Master Home Switch	ON
X22.2 Y-Axis Overtravel	OFF	X22.3 Z-Axis Home Switch	OFF
X22.4 Unused	OFF	X22.5 Dust Hood Up	ON
X22.6 Unused	OFF	X22.7 Unused	OFF

<
CONFIG
MANUAL CTRL
I/O IN
I/O OUT
DRILL BLOCK

LDR SETUP
MCN SETUP
ATC SETUP
FP DEBUG
?

I/O - Input 2/3

X23.0 Unused	OFF	X23.1 Light Curtain OSSD1	OFF
X23.2 Light Curtain OSSD2	OFF	X23.3 Unused	OFF
X23.4 Unused	ON	X23.5 Right Cup Up Sensor	ON
X23.6 Unused	OFF	X23.7 Vacuum Alarm Sensor	OFF
X24.0 Unused	ON	X24.1 Unused	OFF
X24.2 Unused	OFF	X24.3 Unused	OFF
X24.4 Unused	OFF	X24.5 Unused	OFF
X24.6 Outfeed Table Clear	ON	X24.7 Unused	OFF
X25.0 Spindle Over Temp	ON	X25.1 Low PSI Alarm Sensor	OFF
X25.2 Unused	OFF	X25.3 Unused	OFF
X25.4 Pushbar Up	ON	X25.5 Chiller Alarm	OFF
X25.6 Unused	OFF	X25.7 Unused	OFF



I/O - Input 3/3

X26.0 Left Cup Retracted Switch	ON	X26.1 Cup Up Switch	ON
X26.2 Left Cup Up Switch	ON	X26.3 Unused	OFF
X26.4 Plunger Up Switch	ON	X26.5 Outfeed Table Full	OFF
X26.6 Labeler Y-Axis Ref	ON	X26.7 Unused	ON
X27.0 Unused	OFF	X27.1 Unused	OFF
X27.2 Unused	ON	X27.3 Labeler X-Axis Ref	ON
X27.4 Loader Out of Sheets	ON	X27.5 Sheet In Position	OFF
X27.6 Plunger Left	ON	X27.7 Unused	ON
X28.0 Unused	OFF	X28.1 Unused	OFF
X28.2 Unused	OFF	X28.3 Unused	OFF
X28.4 Unused	OFF	X28.5 Unused	OFF
X28.6 Unused	OFF	X28.7 Unused	OFF



32.3 I/O Output Screen



Use the buttons to toggle through the screens.

I/O – Output 1/3

Y4.0 Drill Block On/Off	OFF	Y4.1 Drill Block Up Solenoid	OFF
Y4.2 Dust Hood Down Solenoid	OFF	Y4.3 Unused	OFF
Y4.4 Unused	OFF	Y4.5 Unused	OFF
Y4.6 Spindle Tool Released	OFF	Y4.7 Drill 9	OFF
Y5.0 Drill 1	OFF	Y5.1 Drill 2	OFF
Y5.2 Drill 3	OFF	Y5.3 Drill 4	OFF
Y5.4 Drill 5	OFF	Y5.5 Drill 6	OFF
Y5.6 Drill 7	OFF	Y5.7 Drill 8	OFF
Y6.0 Light Tower – Green	ON	Y6.1 Light Tower – Yellow	OFF
Y6.2 Light Tower – Red	OFF	Y6.3 Spindle CCW	OFF
Y6.4 Table Vacuum Break Valve	OFF	Y6.5 MPG LED	OFF
Y6.6 Z-Brake Release	ON	Y6.7 Drill Block Down Solenoid	OFF

<

CONFIG

MANUAL
CTRL

I/O
IN

I/O
OUT

DRILL
BLOCK

LDR
SETUP

MCN
SETUP

ATC
SETUP

FP
DEBUG

ABOUT

>

I/O - Output 2/3

Y7.0 Vacuum Pump 1	OFF	Y7.1 Vacuum Pump 2	OFF
Y7.2 Oiler	OFF	Y7.3 Front Stop Pop-Up Pins	OFF
Y7.4 Left (X-) Edge Guide Up	OFF	Y7.5 Right (X+) Edge Guide Rail	OFF
Y7.6 Mister	OFF	Y7.7 Vacuum Gate Valve to Table	OFF
Y8.0 Start Outfeed Table	OFF	Y8.1 Drill Block Down	OFF
Y8.2 Machine Lift Cup Suction	OFF	Y8.3 Machine Lift Cup Blow	OFF
Y8.4 Left Shift Cylinder	OFF	Y8.5 Front Dust Port Blast Gate	OFF
Y8.6 Right Cup Down	OFF	Y8.7 Push Bar Down	OFF
Y9.0 TTO Air Blower	OFF	Y9.1 TTO Module Up/Dn	OFF
Y9.2 Extend Loader Cup Piston	OFF	Y9.3 Retract Loader Cup Piston	OFF
Y9.4 Loader Cup Up/Dn Solenoid	OFF	Y9.5 Loader Cup Suck	OFF
Y9.6 Loader Cup Blow	OFF	Y9.7 Labeler Plunger Up/Dn	OFF

<
CONFIG
MANUAL CTRL
I/O IN
I/O OUT
DRILL BLOCK
LDR SETUP
MCN SETUP
ATC SETUP
FP DEBUG
ABOUT
?



I/O - Output 3/3

Y10.0 Label Foot Vacuum On/Off	OFF	Y10.1 Air Blast Under Label	OFF
Y10.2 Panel Sensor Blower	OFF	Y10.3 Right Air Jet	OFF
Y10.4 Front Air Jet	OFF	Y10.5 Left Air Jet	OFF
Y10.6 Back Air Jet	OFF	Y10.7 Labeler Plunger Left/Right	OFF
Y11.0 Rotate Labeler Foot 90 deg	OFF	Y11.1 Unused	ON
Y11.2 Drill Block Dust Port	ON	Y11.3 Unused	OFF
Y11.4 Unused	OFF	Y11.5 Unused	OFF
Y11.6 Unused	OFF	Y11.7 Unused	OFF

<
CONFIG
MANUAL CTRL
I/O IN
I/O OUT
DRILL BLOCK
LDR SETUP
MCN SETUP
ATC SETUP
FP DEBUG
ABOUT
?

32.4 Loader Setup



When prompted, press the  button set value(s).  will turn white when the feature is prompted.

LOADER SETUP

#500 Panel Align Start X Position

#501 Panel Align Start Y Position

#502 Load Start X Position

#503 Load Start Y Position

#504 Stage Panel Y Distance

#505 New Bunk X Position

#506 New Bunk Y Position

EXT External Offset X Position


EXT External Offset Y Position


D704 Panel Await Timeout


INPUT VALUE:


44.0000	INCH
39.0000	INCH
24.0000	INCH
34.0000	INCH
-28.2500	INCH
51.0000	INCH
109.0000	INCH
0.5000	INCH
0.8750	INCH
0.0900	SEC


TEACH











	ABSOLUTE	MACHINE		REF	***	****	***	*****	***
X	51.9963	52.4963	INCH MACHINE	REF	***	****	***	*****	***
Y	108.9973	109.8723	INCH LABELER	MDI	***	****	***	*****	***

<

CONFIG

MANUAL CTRL

I/O IN

I/O OUT

DRILL BLOCK

LDR SETUP

MCN SETUP

ATC SETUP

FP DEBUG

ABOUT

?

32.5 Machine Setup

MACHINE SETUP

INPUT VALUE:

#531 Table Sweep Y Position	115.0000	INCH
#532 Panel Drop Y Position	11.0000	INCH
#533 Panel Loading Feedrate	4000000	0.0001 INCH/MIN
#534 Table Sweep Feedrate	3000000	0.0001 INCH/MIN
#535 Y Axis Panel Positioning Feedrate	500000	0.0001 INCH/MIN
#536 4x8 Panel Center Y Position	52.0000	INCH
#537 5x10 Panel Center Y Position	0.0000	INCH
#538 5x12 Panel Center Y Position	0.0000	INCH
#540 Panel Shift to Pop-Up Y Distance	11.2500	INCH
#541 Panel Pickup Y Position	115.0000	INCH
EXT External Offset X Position	4.0245	INCH
EXT External Offset Y Position	22.4236	INCH

	ABSOLUTE	MACHINE					
X	45.3001	49.3246	INCH				
Y	103.0197	125.4433	INCH	MACHINE	REF	***	****
Z	-0.6234	-0.0634	INCH	LABELER	MDI	***	****

<
CONFIG
MANUAL
CTRL
I/O
IN
I/O
OUT
DRILL
BLOCK

LDR
SETUP
MCN
SETUP
ATC
SETUP
FP
DEBUG
ABOUT
?

TEACH

32.6 ATC Setup Screen

ATC SETUP

INPUT VALUE:

TEACH

#500 Tool Change X Position	67.6516	INCH
#501 Tool Change Down Z Position	-10.3360	INCH
#502 Tool Change Up Z Position	-8.4953	INCH
#503 TTO Max Negative Z Position	-11.0000	INCH
#504 Sensor-Table Z Difference	0.2132	INCH
#505 TTO X Position	49.3200	INCH
#506 TTO Y Position	125.4460	INCH
#507 TTO Starting Z Position	-6.8000	INCH
#509 Max Tool Number	16	

	ABSOLUTE	MACHINE							
X	45.3001	49.3246	INCH						
Y	103.0197	125.4433	INCH	MACHINE	REF	***	****	***	*****
Z	-0.6234	-0.0634	INCH	LABELER	MDI	***	****	***	*****

<
CONFIG
MANUAL CTRL
I/O IN
I/O OUT
DRILL BLOCK

LDR SETUP
MCN SETUP
ATC SETUP
FP DEBUG
ABOUT
?

32.7 Debug Screen

DEBUG


ADDRESS	SCRIPT	VALUE	ADDRESS	SCRIPT	VALUE
E1400	CompiledTest	0	E1428	AutoQueue	0
E1402	HashStore	0	E1430	Tool0TM	0
E1404	FileHashStore	0	E1432	ProgExecutor	0
E1406	ListDisplay	0	E1434	jobMgrDisp	0
E1408	Startup	0	E1436	ClearDone	0
E1410	jobMgrLists	0	E1438	ClearDoneMode	0
E1412	ProgramStorage	0	E1440		0
E1414	HashList	0	E1442		0
E1416	PMData	0	E1444	DrillSetupTMR	0
E1418	JobKeys	0	E1446		0
E1420	Teach	0	E1448		0
E1422	ScrnCategory	0	E1450		0
E1424	RecoveryTMR	0	E1452		0
E1426	Recovery	0	E1454		0

<
CONFIG
MANUAL CTRL
I/O IN
I/O OUT
DRILL BLOCK


LDR SETUP
MCN SETUP
ATC SETUP
FP DEBUG
ABOUT
>

33.0 Help Screens



To access the help screen, press .

The help screen(s) show the help screen and the M-Codes for the machine and loader.



33.1 Machine M-Codes



This screen shows the M-Codes for the Machine side. Use the buttons to toggle through the screens.

MACHINE M-CODES (1/2)

M03	Spindle On (CW)	M48	Dust Hood Up
M04	Spindle On (CCW)	M49	Dust Hood Down
M05	Spindle Stop	M50	Reset Rapids
M06	Tool Change	M51	Clear Panel Staged
M13	Drill Block On	M52	Drill Block Down
M15	Drill Block Off	M53	Drill Block Up
M30	Program End	M56	All Cups Down
M33	TTO Blower On	M57	All Cups Up
M34	TTO Blower Off	M60	Pump 1 Off
M37	Load Panel	M61	Pump 2 Off
M38	Align Panel	M62	Front PuP Down
M41	Clear Table - No Panel Load	M63	Front PuP Up
M42	Reset Table & Lower Rails	M64	Left Guide Rail Up
M46	Mister On	M65	Left Guide Rail Down
M47	Mister Off	M66	Right Guide Rail Up

S HELP MCN M CODES LDR M CODES PAGE DOWN X

MACHINE M-CODES (2/2)

M67	Right Guide Rail Down	M99	Program Return
M68	Push Bar Down	M105	Enable Automatic airjets
M69	Push Bar Up	M106	Disable Automatic Airjets
M70	Left Push Extend	M114	Lift Cup Suction Off
M71	Left Push Retract	M115	Await Panel Staged
M72	Left Cup Down	M120	Panel Sensor Blower On
M73	Left Cup Up	M121	Panel Sensor Blower Off
M74	Vacuum Gate Open	M122	Back Airjet On
M75	Vacuum Gate Closed	M123	Back Airjet Off
M76	Front Dust Gate Closed	M130	Auto Queue Good Program End
M77	Front Dust Gate Open	M140	Robot Command
M78	Lift Cups Release	M401	Automatic Tool Touch Off
M79	Right Cup On		
M80	Attach Lift Cups		
M90	Reset Skip Load		

S HELP MCN M CODES LDR M CODES PAGE UP X

33.2 Loader M-Codes

LOADER M-CODE

M51	Set Panel Staged	M92	Cup Down
M60	Apply Label	M95	Suction Cup Attach
M61	Stage Panel	M96	Suction Cup Release
M62	Align Panel	M110	Printer Start
M81	Printer Plunger Up	M111	Next Label
M82	Printer Plunger Down	M114	Lift Cup Suction Off
M83	Printer Plunger Left	M115	Await Panel Not Staged
M84	Printer Plunger Right	M120	Sensor Blower On
M85	Rotate Foot 0 Deg	M121	Sensor Blower Off
M86	Rotate Foot 90 Deg	M130	Auto Queue Good Program End
M87	Label Foot Suction On		
M88	Label Foot Suction Off		
M89	Push Material to Fence		
M90	Cup Piston Retract		
M91	Cup Up		

S HELP MCN M CODES LDR M CODES X

34.0 Emergency Recovery

The emergency recovery is a function that resets the machine to its default mode.

The emergency recovery should only be used if the machine is not functioning correctly and cannot be troubleshooted with the assistance of a trained Laguna representative.

To perform an emergency recovery:

1. Press **edit mode> Prog> folder> operate> device change> CF> Select *joblist.dat*> delete**
2. Power the machine off. Wait 10 seconds.(this allows the machine to shut down correctly)
3. Turn the machine on. Wait for the machine to power up.
4. Turn the machine off again and wait 10 seconds.
5. Turn the machine on again and wait for the machine to power up.

35.0 Maintenance

As with any machine, to ensure optimal performance you must conduct regular maintenance.

Failure to follow maintenance procedures will void the warranty.

 **WARNING**

Always disconnect power to the machine before performing maintenance. Failure to do this may result in serious personal injury or damage to the machine.

Table 30-1: Maintenance Table

Table is based on 30 hours of use a week						
	Daily	Weekly	Monthly	Every 500 Machine Hours	Yearly	As Needed
Wipe the ballscrews and prismatic guides and ensure they are dust free.	X					
Apply a 3 in 1 light machine oil to ballscrews and prismatic linear guides using a clean cloth. Move the machine through travel limits to properly disperse lubricant.	X					
Refill the oil reservoir with a 30 weight non-synthetic motor oil.						X
Remove all tooling from the spindle at the end of the day. Do not leave any tooling in the spindle overnight. This includes tool cones, collets, router bits, etc.	X					

SmartShop 4 Auto Loader Owner's Manual


Leaving any tooling in the spindle overnight can cause the tooling to get dirty, stuck, rust, and cause damage to the spindle.						
Check that all electrical connectors are fitted correctly and are not loose.	X					
Check coolant levels in reservoir.	X					
Check the tool blades for chips and dullness	X					
Ensure that slots in the collets are free of sawdust and debris.	X					
Clean the collets and spindle holes. Uncleaned spindle holes may affect cut quality and pose a safety hazard if significantly dirty.	X					
Clean the router bits	X					
Clean surface dust	X					
Clean the x and y-axis rack rails and the z-axis screw guides	X	X				
Check the dust extraction for blockages, as large pieces could cause blockages	X	X				
Inspect the overall machine for damage and loose or worn parts.	X	X		X		
Clean machine with compressed air			X			
Disconnect power at the wall and clean the dust form the cabinet and fan covers			X			

35.1 Cleaning the Helical Racks

The helical racks on the SmartShop Auto Loader may collect dust and debris which can interfere with the smooth operation of the gantry and spindle. Clean with a plastic brush, following the angle of the grooves. Lubricate with a thin layer of lithium grease; gently wipe away excess.

35.2 Cleaning the Spindle Tray

The spindle tray will accumulate oil and may drip onto the worktable or project if not kept clean. To clean the tray, remove the four (4) Allen screws shown in the figure below and wipe the tray clean.



Replace and tighten Allen nuts until snug; do not overtighten.

36.0 Troubleshooting

Problem	Causes	Solution
Vacuum pump blowing, not sucking	Wiring is faulty	Switch wires to different terminals
Spoil board has poor suction	Spoil board has moisture in it	Replace the spoil board
Vacuum pump does not reach operating speed when starting	<ul style="list-style-type: none"> • Connections are not fully connected • Incorrect voltage and frequency • Loose nuts on wire connection slices 	<ul style="list-style-type: none"> • Check the connections on the motor terminal block • Check the incoming voltage and frequency corresponds with the motor data plate • Check the nuts are screwed to the wire connection slices
Motor Starter cuts out blower	<ul style="list-style-type: none"> • Incorrect setting on the motor starter • Motor starter trips too fast • Blower is overloaded i.e. pressure difference is too high) 	<ul style="list-style-type: none"> • Check the motor data plate and set • Use a motor starter with a time delay trip • Increase the inlet or outlet diameter of the application, on pipework increase the diameter of the pipework, avoid restrictions in the line. Limit the pressure different by limitation valves.
Required pressure difference cannot be achieved	<ul style="list-style-type: none"> • Blower or motor rating selected was too small • Filters are contaminated • Pressure loss into pipe diameter, avoid restrictions • Leaks on the system 	<ul style="list-style-type: none"> • Clean filters or change filters if necessary • Use bigger pipe diameter.
Automatic tool changer not working	<ul style="list-style-type: none"> • Air compressor not turned on • Air hose incorrectly connected. • Moisture in the air line 	<ul style="list-style-type: none"> • Confirm air compressor is on • Confirm air hose is connected correctly. • Attach an air dryer system and remove the moisture
Labeler is producing low quality prints	<ul style="list-style-type: none"> • Dust collection tray is dirty • 	<ul style="list-style-type: none"> •

37.0 Warranties

Dealer Machinery Warranty

New woodworking machines sold by Laguna Tools carry a two-year warranty effective from the date of dealer invoice to customer/end-user. Machines sold through dealers must be registered with Laguna Tools within thirty (30) days of purchase to be covered by this warranty. Laguna Tools guarantees all new machines sold to be free of manufacturers' defective workmanship, parts, and materials. We will repair or replace, without charge, any parts determined by Laguna Tools, Inc. to be a manufacturer's defect. We require that the defective item/part be returned to Laguna Tools with the complaint. The end-user must request a Return Material Authorization (RMA) number from Customer Service. Include the RMA number with any and all returned parts/components requesting warranty coverage*. Any machines returned to Laguna Tools must be returned with packaging in the same manner in which it was received. A part or blade is being returned must have adequate packaging to ensure it is not damaged during shipping. In the event the item/part is determined to be damaged due to lack of maintenance, cleaning, or misuse/abuse, the customer will be responsible for the cost to replace the item/part, plus all related shipping charges. This limited warranty does not apply to natural disasters, acts of terrorism, normal wear and tear, product failure due to lack of maintenance or cleaning, damage caused by accident, neglect, lack of or inadequate dust collection, misuse/abuse or damage caused where repair or alterations have been made or attempted by others.

* The issue of an RMA number is for reference only; it DOES NOT indicate acceptance of the warranty claim.

CNC Limited Warranty

New CNC machines sold by Laguna Tools carry a one-year warranty effective from the date of shipping. Laguna Tools guarantees all new machines sold to be free of manufacturers' defective workmanship, parts, and materials. We will repair or replace, without charge, any parts determined by Laguna Tools, Inc. to be a manufacturer's defect. If the defective item/part is determined to be damaged due to lack of maintenance, cleaning or misuse/abuse, the customer will be responsible for the cost to replace the item/part, plus all related shipping charges. This limited warranty does not apply to natural disasters, acts of terrorism, normal wear and tear, product failure due to lack of maintenance or cleaning, damage caused by accident, neglect, lack of or inadequate dust collection, misuse/abuse or damage caused where repair or alterations have been made or attempted by others.

Laguna Tools, Inc. is not responsible for additional tools or modifications sold or performed (other than from/by Laguna Tools, Inc.) on any Laguna Tools, Inc. woodworking and/or metalworking machine. The warranty may be voided upon the addition of such described tools and/or modifications, determined on a

SmartShop 4 Auto Loader Owner's Manual

case-by-case basis. Software purchased through Laguna Tools, Inc., is not covered under this warranty and all technical support must be managed through the software provider. Normal user alignment, adjustment, tuning, and machine settings are not covered by this warranty. It is the responsibility of the user to understand basic woodworking machinery settings and procedures and to properly maintain the equipment in accordance with the standards provided by the manufacturer.

Parts under warranty are shipped at Laguna Tools, Inc.'s cost either by common carrier, FEDEX ground service, or a similar method. Technical support to install replacement parts is primarily provided by phone, fax, e-mail or Laguna Tools Customer Support Website. The labor required to install replacement parts is the responsibility of the user. Laguna Tools is not responsible for damage or loss caused by a freight company or other circumstances not in our control. All claims for loss or damaged goods must be notified to Laguna Tools within twenty-four (24) hours of delivery.

Please contact our Customer Service Department for more information. Only NEW machines sold to the original owner are covered by this warranty.

For warranty repair information, call 1-800-332-4094.

Warning: No portion of these materials may be reproduced without written approval from Laguna Tools, Inc.

Copyright© 2025 Laguna Tools, Inc.

No Modifications Allowed or sold

Laguna Tools, Inc. is not responsible for additional tools or modifications sold or performed (other than from/by Laguna Tools, Inc.) on any Laguna Tools, Inc. woodworking and/or metalworking machine. The warranty may be voided upon the addition of such described tools and/or modifications, determined on a case-by-case basis. Software purchased through Laguna Tools, Inc., is not covered under this warranty and all technical support must be managed through the software provider. Normal user alignment, adjustment, tuning, and machine settings are not covered by this warranty. It is the responsibility of the user to understand basic woodworking machinery settings and procedures and to properly maintain the equipment in accordance with the standards provided by the manufacturer.

Parts under warranty are shipped at Laguna Tools, Inc.'s cost either by common carrier, FEDEX ground service, or a similar method. Technical support to install replacement parts is primarily provided by phone, fax, e-mail or Laguna Tools Customer Support Website. The labor required to install replacement parts is the responsibility of the user. Laguna Tools is not responsible for damage or loss caused by a freight company or other circumstances not in our control. All claims for loss or damaged goods must be notified to Laguna Tools within twenty-four (24) hours of delivery.

SmartShop 4 Auto Loader Owner's Manual

Please contact our Customer Service Department for more information. Only NEW machines sold to the original owner are covered by this warranty.

For warranty repair information, call 1-800-332-4094.

Warning: No portion of these materials may be reproduced without written approval from Laguna Tools, Inc.

Copyright 2025 Laguna Tools, Inc.

No Modifications Allowed or Sold

Laguna Tools, Inc. is not responsible for additional tools or modifications sold or performed (other than from/by Laguna Tools, Inc.) on any Laguna Tools, Inc. woodworking machine. The warranty may be voided upon the addition of such described tools and/or modifications, determined on a case-by-case basis. Normal user alignment, adjustment, tuning, and machine settings are not covered by this warranty. It is the responsibility of the user to understand basic woodworking and/or metalworking machinery settings and procedures and to properly maintain the equipment in accordance with the standards provided by the manufacturer. Parts, under warranty, are shipped at Laguna Tools, Inc.'s cost either by common carrier, FEDEX ground service or a similar method. Technical support to install replacement parts is primarily provided by phone, fax, e-mail, or Laguna Tools Customer Support Website. The labor required to install replacement parts is the responsibility of the user. Laguna Tools is not responsible for damage or loss caused by a freight company or other circumstances not in our control. All claims for loss or damaged goods must be notified to Laguna Tools within twenty-four (24) hours of delivery. Please contact our Customer Service Department for more information. Only new machines sold to the original owner are covered by this warranty.

For warranty repair information call 1-800-332-4094.

SmartShop 4 Auto Loader Owner's Manual

Laguna Tools Warranty

WARRANTY & REGISTRATION

Thank You!

Welcome to the Laguna Tools® group of discriminating industrial machinery owners. We understand that you have a choice of where to purchase your machines and appreciate the confidence you have in the Laguna Tools® brand.

Through hands-on experience, Laguna Tools® is constantly working hard to make innovative, precision products. Products that inspire you to create works of art are a joy to operate and encourage your best work.

Laguna Tools®
Imagination, Innovation, and Invention at Work

Warranty & Registration

Every product sold is warranted to be free of manufacturer's defective workmanship, parts, and materials. For any questions about this produce, the intended use or what it was designed for, customer service, or replacement parts, please contact our customer service department:

Laguna Tools® Customer Service
744 Refuge Way, Grand Prairie, Texas 75050, USA
1-800-234-1976
customerservice@lagunatools.com
www.lagunatools.com/why/customer-service/
8AM. To 5PM PSF. Monday through Friday

For warranty claims or to report damage upon receiving-please reach out to our warranty department:

Laguna Tools® Warranty Service
744 Refuge Way, Grand Prairie, Texas 75050, USA
1-800-234-1976
customerservice@lagunatools.com
www.lagunatools.com/policies/warranty
8AM to 5PM PST, Monday through Friday

Registration

To prevent voiding this warranty, all products sold must be registered within thirty (30) days of receiving the product. Registering the product will enable the original purchaser to receive notifications about important product changes, receive customer service, and be able to file a warranty claim against defective workmanship, parts, or materials.



Who is Covered

The applicable warranty covers only the initial purchaser of the product from the date of receiving the product. To file such claims, the original purchaser must present the original receipt as proof of purchase.

What is Covered

The warranty covers any defects in the workmanship of all parts and materials that make up the machine unless otherwise specified. Any part determined by Laguna Tools® to have a defect will be repaired or replaced (and shipped), without charge. The defective item/part must be returned to Laguna Tools® with the complaint and proof of purchase in the original packaging that it was received in. In the event the item/part is determined to be not covered by this warranty, the customer will be responsible for the cost to replace the item/part and all related shipping charges

Warranty Limitations

This limited warranty does not apply to natural disasters, acts of terrorism, normal wear and tear, product failure due to lack of maintenance or cleaning, damage caused by accident, neglect, or lack-of inadequate dust collection. The warranty may be voided against proof of misuse/abuse, damage caused where repair or alterations have been made or attempted by others, using the product for purposes other than those described as intended use (unless with consent by Laguna Tools®), modification to the product, or use with an accessory that was not designed for the product. It is the responsibility of the user to understand basic woodworking machinery settings and procedures and to properly maintain the equipment in accordance with the standards provided in this manual.

Length of Warranty

All new machines and optional accessories sold through an authorized dealer carry a two-year warranty effective from the date of receiving the product. Machines sold for either commercial or industrial use have a one-year warranty. Wearable parts like throat plates, bandsaw guides, etc., have a ninety-day warranty.

Table A-1 Warranty Lengths

2 Year – New Machines Sold Through an Authorized Dealer
2 Year – Accessories Sold as Machine Options (excluding blades)
1 Year – Machines Sold for Commercial or Industrial Use
1 Year – Blades and Accessories outside of Machine Options
90 Days – Wearable Parts

Aside from being free of defects upon receiving, consumable parts, like cutters and abrasives, are not covered by this warranty unless otherwise stated by Laguna Tools®. These parts are designed to be used at the expense of the operator and are available for replacement or inventory purchase. The determination of a consumable part will be made on a case-by-case basis by Laguna Tools®.

Shipping Damage

Laguna Tools® is not responsible for damage or loss caused by a freight company or other circumstances not in the direct control of Laguna Tools®. All shipping-related claims for loss or damage to goods must be made to Laguna Tools® within twenty-four hours of delivery.

How to Receive Support

To file a warranty claim, please contact the warranty department at 1-800-234-1976. To receive customer service or technical support, please contact the customer service department at 1-800-332-4094. Parts, under warranty, are shipped at the expense of Laguna Tools® either by common carrier, FedEx ground services or similar method. Technical support to install replacement parts is primarily provided by phone, fax, email, or the Laguna Tools® Customer Service Support Website.



© 01/2025 Laguna Tools, Inc.

LAGUNA

Laguna Tools, Inc.

744 Refuge Way, Suite 200

Grand Prairie, TX 75050

1-800-234-1976

www.lagunatools.com

Copyright © 2025 Laguna Tools, Inc. All rights reserved.